

Neigungssensoren /displacement sensor

Burny Pin # ! Count without "I" !	Farbe FS Kabel Farben nach DIN 47100	Used as / Function: (Based on "DIS Sensors" "QG65-KD-....." with M12 connector)	Color for "DIS Sensors" "QG40-KD-
A	white	Output Y 0,5-4,5V	white
B	brown	Supply Voltage (8-30V) Try to use 12V	brown
C	green	Programming interface RS232 Rx	
D	yellow	Programming interface RS232 Tx	
E	gray	GND (PWR)	blue
F	purple	Centering Input (GND orientated leave open)	
G	blue	Output X 0,5-4,5V	black
H	red	Shield of device	
J		short to "#E" GND "Sig output"	short to "#E" GND "Sig output"
K		short to "#E" GND "RS232 and or Center"	
L			
M	Shield of cable	Shield of cable	