


LaVue - NeXus File

Images from a Nexus/Hdf5 file, e.g. written in the SWMR mode (Single-Writer-Multiple-Reader) or after the scan.



The NeXus File image source frame contains the following fields:

- **File:** nexus file name with its full path e.g. `/gpfs/current/H2O_test.nxs`
- **Field:** nexus field with its path inside nexus file e.g. `/entry12345/data/lambda`
- **Stacking:** stacking dimension of images inside a 3D field. Usually, for Nexus format is 0, i.e. the first dimension.
- **Frame:** nexus field frame to display. The default value is -1, i.e. the last frame.
- **Status:** shows the connection status. It also displays a port of ZMQ security stream if it is enabled.
- **Start/Stop** button to launch or interrupt image querying